



iBook G3 Clamshell LCD Bezel Replacement

Replacing the bezel covering the Lcd

Written By: aidan



INTRODUCTION

Replacing the bezel covering the Lcd



TOOLS:

- [T8 Torx Screwdriver](#) (1)
 - [Flathead Screwdriver](#) (1)
-

Step 1 — Battery Cover



- Use a coin to unscrew the battery cover, and remove battery.

Step 2 — Back Cover




- Use a t8 Torx driver to unscrew the two screws holding in the back cover, then remove the cover.

Step 3



- Open the screen, and remove the two t8 Torx screws holding the bezel in place.

Step 4



- Use a flat tip screw driver to unsnap the bezel from its place.
- When at the top rubberized area, pry the bezel down.

To reassemble your device, follow these instructions in reverse order.

